

FPASS

Απομακρυσμένη έναρξη/λήξη

For the remote start of all FRIAMAT fusion units from the trench using a reader wand or barcode scanner. Lanyard included.

