

Vent cowl



Reference	Name	tooltipImage	L	Code	Subcategory	Diameters	Q
WYW-050-000-000T	Vent cowl	-	108	WYW-050-000-000T	Branches	50, 75, 110, 160	-
WYW-075-000-000T	Vent cowl	-	108	WYW-075-000-000T	Branches	50, 75, 110, 160	20
WYW-110-000-000T	Vent cowl	-	121	WYW-110-000-000T	Branches	50, 75, 110, 160	20
WYW-160-000-000T	Vent cowl	-	151	WYW-160-000-000T	Branches	50, 75, 110, 160	20